

INSTALLATION GUIDE FOR CCY5032MBK and CCY5032BRG



SAFETY INFORMATION

Released Date: 2024-09-29

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING

- RISK OF ELECTRIC SHOCK Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.
- RISK OF FIRE Use bulbs specified by the markings and/or labels on the fixture.

CAUTION

- · For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.
- Turn off electricity to fixture before replacing the bulb(s).

TOOLS REQUIRED













CARE AND MAINTENANCE


• Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage the finish.


If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS












x 1

MOUNTING HARDWARE




















Outlet Box Screw




















Your installation is now complete! Restore electricity and save this sheet for future reference.