

INSTALLATION GUIDE FOR BYS640MBK



SAFETY INFORMATION

Released Date: 2024-09-10

Wattage

51W

120~277Vac, 50~60Hz

Model No.

BYS640MBK

Ratings

Please read and understand this entire manual before attempting to assemble, install or operate the product.

WARNING

RISK OF ELECTRIC SHOCK - Before beginning installation, turn off electricity at the circuit breaker box or the main fuse box.

- For your safety, read instructions completely before beginning installation.
- If in doubt about electrical installation, consult a licensed electrician.

TOOLS REQUIRED












CARE AND MAINTENANCE


Wipe clean using soft, dry cloth or static duster. Always avoid using harsh chemicals and abrasives to clean fixture as they may damage

If you need further assistance call Quoizel Customer Care at 1-800-645-3184 (9:00am - 5:00pm EST), or visit us on-line at www.quoizel.com.

PACKAGE CONTENTS



MOUNTING HARDWARE




















Mounting Screw



Outlet Box Screw










IMPORTANT: PLEASE READ CAREFULLY BEFORE INSTALLATION!


- This fixture uses steel cables that are current carrying wires. The cables are safe to touch when only touching one cable. Do NOT allow
 the cables to touch each other and do not touch two cables at the same time, after power has been connected. The current carrying
 wires uses low voltage which is safe if touched accidently.
- The fixture has a short circuit protection. If any of the following situations occurs unexpectedly, the fixture will power off.
 - 1. Steel cables are touched by another steel cable unexpectedly
 - 2. Steel cables are twisted around another.


If any of the above occurs, it may cause a spark where the cables touch which will cause the fixture to power off. If this occurs, turn the wall switch off and confirm that the steel cables are not touching another cable. This includes inside the canopy and the visible cables outside the canopy. Then turn the wall switch back on.


- To prevent potential risks, please make sure that the fixture body is level after adjustment.
- The fixture hanging height cannot be adjusted after installation. Before power on the fixture the first time, please make sure that you have achieved the desired hanging height. For safety purpose, the extra steel cables inside of the ceiling canopy will be cut off and insulated by using plastic tubes. Please refer to the relative steps of insulating steel cables as below.


INSTALLATION











Your installation is now complete! Restore electricity and save this sheet for future reference.